



ALFA ROMEO 105 OIL FILTER ADAPTOR FITTING INSTRUCTIONS

Please read all the instructions before starting work on your car.

The kit contains:

- Large o-ring
- Small o-ring
- Aluminium adaptor plate
- Bolt 948
- Alfa 105 extension bolt (not shown)
- Oil filter

(This diagram is for illustration purposes only)



Remove the bowl containing the original filter. Remove the old filter and the sealing ring which sits in a groove in the filter head.

Place the large seal supplied with this kit in the groove in the filter head. The smaller o-ring should be fitted into the inner recess of the adaptor plate. Take the cannister bolt (948) and screw down tight onto the extension bolt then insert this bolt through the adaptor plate and offer up to the filter head. Now screw up to the original filter head bolt. Tighten using a 1"AF socket but do not over-tighten.

You are now ready to fit a spin-on filter. We recommend a Crosland 357, Mann W916/1 or similar high quality filter. Remember to grease the filter seal before fitting. Change at the usual intervals.

Never tighten a spin-on filter with a filter removal tool.

N.B. Once you have fitted a Flexolite oil filter adaptor it is easy to fit a Flexolite oil cooler kit – ask for details.

Also available - braided stainless steel fuel lines, braided stainless steel brake hoses.