



FORD 105E OIL FILTER ADAPTOR KIT

Please read all the instructions before starting work on your car.

The kit contains:

- Large rubber seal
- Small o-ring
- Extension tube
- Dowty washer
- Aluminium adaptor plate
- Cannister bolt 948
- Oil filter



(This diagram is for illustration purposes)

Remove the old filter bowl and filter. Remove the old seal in the groove in the pump body. Fit the new seal supplied.

Place the o-ring supplied over the central spigot in the filter adaptor plate and place the adaptor plate in position on the pump.

Insert the long bolt (with its seal) through the pump body and insert the hollow bolt (with its extension tube) up through the filter adaptor plate. Screw the two bolts together but do not over-tighten.

You are now ready to fit a modern spin-on filter. We recommend a Crosland 2022 or similar high-quality filter.