



VAN DEN PLAS 4 LITRE R OIL FILTER ADAPTOR FITTING INSTRUCTIONS

Please read all the instructions before starting work on your car.

The kit contains:

- Large rubber seal
- Aluminium adaptor plate
- Small o-ring
- Bolt 948
- Oil filter



(This diagram is for illustration purposes only and may not be identical to the kit you have been supplied.)

Remove the bowl containing the original filter. Remove the old filter and the sealing ring which sits in a groove in the filter head.

Place the larger of the two o-rings supplied with this kit in the groove in the filter head. Place the adaptor plate with the narrow outer face uppermost and place the rubber o-ring in the central groove in the plate. Put the plate in position, making sure that it sits in the groove in the filter head. Insert the locating bolt through the plate and screw into the filter head. Tighten but do not over-tighten.

You are now ready to fit a spin-on filter. We recommend a Crosland 357, Coopers Z27A or similar quality filter, Remember to grease the filter seal before fitting. Change at the usual intervals.