



VAN DEN PLAS/PRINCESS DM4 WITH POWER STEERING

OIL FILTER ADAPTOR FITTING INSTRUCTIONS

Please read all the instructions before starting work on your car.

The kit contains:

- Rubber seal
- Aluminum adaptor plate
- Adaptor bolt
- Copper washer
- Oil filter



Remove the original filter bowl and its sealing ring (which may be stuck in the filter head). Fit the large diameter o-ring supplied into the groove in the filter head.

Remove the central splash plate (a large steel “washer” and the felt washer if one is there).

Using the copper washer with the adaptor bolt, place the adaptor plate in position. Screw in the adaptor bolt by hand. Using a 1" AF socket tighten the adaptor bolt fully (but do not over tighten).

When fitting a new spin-off filter always fill it with oil before screwing it on to the adaptor. Always check for leaks after fitting a filter and after fitting the adaptor for the first time.

Use a Fram PH2857A, Mann W916/1 or similar oil filter. Remember to grease the square seal on the filter before fitting.