



**SUNBEAM TALBOT MKIII,  
HUMBER HAWK SERIES II**

**OIL FILTER ADAPTOR FITTING INSTRUCTIONS**

**Please** read all the instructions before starting work on your car.

The kit contains:

- 567 rubber seal
- O-ring
- Aluminum adaptor plate
- Bolt
- Extension tube
- Filter Bolt (948)
- $\frac{3}{8}$ " copper washer (not shown)
- Oil filter



*(This diagram is for illustration purposes only as it does not show the bolt, extension tube or copper washer which is required for this kit.)*

Remove the bolt, bowl, and original filter. Remove the oil seal which sits in the groove in the filter head and clean the groove.

Place a new seal in the groove in the filter head. Place the o-ring supplied over the central spigot in the filter adaptor plate and place the adaptor plate in position. Insert the bolt with the washer through the filter body and insert the 948 bolt (with its extension tube) up through the filter adaptor plate. Screw the two bolts together but do not over-tighten.

With your adaptor use a Mann W730/1 filter (or similar high quality filter with a 3/4UNF thread). Change the filter at the originally recommended intervals.

Ask for details on oil coolers, flexible oil and fuel lines, fuel filters, and braided stainless steel brake hoses available from Flexolite.