



## ALFA ROMEO 1600 'COMIT' OIL FILTER ADAPTOR FITTING INSTRUCTIONS

**Please** read all the instructions before starting work on your car.

The kit contains:

- Large o-ring
- Aluminium adaptor plate
- Cannister bolt
- Oil filter

*(This diagram is for illustration purposes only)*



Remove the bowl containing the original filter. Remove the old filter and the sealing ring which sits in a groove in the filter head.

Place the large seal supplied with this kit in the groove in the filter head. Using the cannister bolt screw through the adaptor plate and fit up to the filter head. Tighten using a 1"AF socket but do not over-tighten.

You are now ready to fit a spin-on filter. We recommend a Mann W916/1 or similar high quality filter. Remember to grease the filter seal before fitting. Change at the usual intervals.

Never tighten a spin-on filter with a filter removal tool.

N.B. Once you have fitted a Flexolite oil filter adaptor it is easy to fit a Flexolite oil cooler kit – ask for details.

Also available - braided stainless steel fuel lines, braided stainless steel brake hoses.